



Zeal Optics iON MicroSD Card Replacement

Replace the MicroSD card in your Zeal Optics iON.

Written By: Eric Flores



INTRODUCTION

When your memory card is full, you can follow these steps to install another microSD card in your iON.

Step 1 — MicroSD Card




- Peel the rubber cover for the memory card and USB port away from the goggles.


⚠ Be careful not to completely remove the cover!

Step 2



- Push the memory card in until you hear it click.
- Pull your finger away.

 If you pull your finger away too quickly, the card can completely pop out of the slot and could get lost!

 The memory card will pop out about half way out of its slot.

Step 3



- Pull the memory card straight out of its slot.

To reassemble your device, follow these instructions in reverse order.

This document was last generated on 2017-07-21 12:45:40 AM.